

DYNAMIC PASS BOX

TI - 81 SERIES

Dynamic Pass Box equipment are made of powder coated high grades stainless steel (304 / 316) with international quality standard components including electrically interlocked doors and UV light. These dynamic pass box equipment are equipped with pre-filter of 5 micron and box type HEPA Filter of 99.999% to 0.3 micron.

Features of Dynamic Pass Box

- High grade stainless steel construction.
- Cleanliness ISO CLASS 100
- Low noise Model.
- Precision designing and finish.
- Electrical interlocked.
- Floor and wall mounted design.
- Buzzer indication to know the material is kept inside.
- Maximum chemical resistance construction.
- Interlocked between U.V. light and LED light
- UV light along with hour meter.
- Indicating lamp to know the door lock-unlock condition.
- Toughen glass window.
- LCD display



TECHNICAL DATA

Model No	Internal Size H X W X D in cm	External Size H X W X D in cm
TI – 81 A-DPB	45 X 45 X 45	90 X 57 X 53
TI – 81 B-DPB	61 X 61 X 61	110 X 73 X 69
TI – 81 C-DPB	75 X 75 X 75	125 X 87 X 83
TI – 81 D-DPB	90 X 90 X 90	142 X 104 X 100

MUMBAI : @ temposales@shandilyagroup.com
(H.O) @ sales@tempo.net.in
☎ +91 9820464003;
+91 9619741622 ;
+91 9820840572

HYDERABAD

@ Email Id:- tempohyd@shandilyagroup.com
☎ +91 9959531765

TEMPO INSTRUMENTS PVT. LTD.

TEMPO HOUSE
Top syringe compound, W.E. Highway, Pandurang wadi, behind
Samrat Hotel, Mira Road (East), Thane-401104
Tel : +91-9820464003 ; Email : sales@tempo.net.in



ISO 9001:2015



ISO 13485:2012

Head Office

10-11, Prospect Chamber Annexe, 317-21, Dr. D.N. Road, Fort,
Mumbai-400001 INDIA
Tel : +91-022-65206102-03, 65208849-50 ; Fax: +91-022-22045352